






Telephone Quick Reference Guide



DS 24 telephones do not have an **ANS/RLS** key but can be programmed using a feature key.

The **ANS/RLS** key can be used to answer a ringing call or hang up.

Making Calls

Internal
External

Dial the extension number.
Press an idle line key or dial '9', then dial the telephone number.

Using the Speakerphone

When using the handset, press **SPEAKER** and hang up.
To disconnect from a hands free call, press **ANS/RLS**
To allow **group listening** press **scroll** key three times, press **listen** soft key.

Hold

Regular
Exclusive

Press the **HOLD** key once.
Press the **HOLD** key twice

This feature will hold a line exclusively on your set and cannot be picked up from another telephone.

Transfer

While talking, press **DSS/BLF** station key or, press the **TRANSFER** key, dial extension. announce the call if required, hang-up or press **ANS/RLS** key to complete the transfer

if you need to return to the caller press the **RETURN** soft key.

Conference Call

Make or receive your first call, press **CONF** key or press **SCROLL . CONF.** press **DSS/BLF** key or, dial extension or outside telephone number, press **CONF** key to add another party or press **CONF** key **twice** to **begin conference.** Maximum of 5 parties can be connected.

**Personal Speed Dial
Programming**

Press **TRANSFER**, dial 105
Enter speed dial memory number (00-49)
Dial '9' and the telephone number
Press **TRANSFER** to store the number

To use personal Speed dial

Press **SPEAKER** or lift handset,
Press speed dial, Enter **2 digit** memory code **00-49**

To use system Speed dial

Press **SPEAKER** or lift handset,
Press speed dial, Enter **3 digit** memory code **500-999**

Last Number Redial

Press **REDIAL** or dial '19'

Automatic Redial

Receive busy tone, press **SCROLL** and press **RETRY**.
The system makes up to 15 attempts to dial the busy
telephone number. Lift and replace handset to cancel.

Headset Operation

Press the **HEADSET** key to disable the handset then use the
ANS/RLS key to answer and disconnect callers

Paging

Lift handset and press **Page** key or
dial '**55**' + **paging group**.
Press * for all call
Page, press **ANS/RLS** key or hang up when complete

Meet Me Paging

Lift handset, dial '**54**' plus **page group**
Press * for all call
Page, press **WAIT** softkey or **Transfer** when done.
Remain off hook

To respond

On any telephone, Lift handset, Dial **56**.

Changing your name

Press **TRANSFER**, dial **104**
Spell your name using the keypad. press
Use the **Volume Keys** to move cursor.
Press **Hold** to erase name
Press **TRANSFER** when complete

Changing intercom mode

Press **TRANSFER**, dial **103**
Use volume keys to set intercom answer mode
Press **TRANSFER** when complete

Call Forward options

Press **TRANSFER**, dial **102**
Use Volume Keys to select forward type
All, Busy, No Answer, Busy/No Answer, DND Auto or External
Press right soft key
Dial extension or group number
To transfer to an external number dial 9 +number.
Use **Volume Keys** to select Yes/No
Press **TRANSFER** when complete
Set Busy and No Answer destinations before selecting
B/NA

Changing Ringing

Press **TRANSFER**, dial **111**
Dial **1** thru **8** or **Volume Keys**
Use Volume Keys to select Yes/No
Press **TRANSFER** when complete

If you have a SVMi series Voicemail system :

To Access Voicemail

Press **VM** key
Enter your **password** default is **0000**
Use the **softkeys** to listen to messages

To transfer a call directly to a mailbox

Press Transfer, Dial Voicemail group
DS16 systems, Voicemail is 509
iDCS systems, Voicemail is 519

When voicemail answers
press *****, **9** + **extension** number
press **ANS/RLS** key or hang up

Using **VMXfer** key

Press **VMXFER**, dial extension
press **ANS/RLS** key or hang up

Shortcuts

57 for mailbox greeting
#71 password
#72 name
#74 enable/disable extended message information prompts

Press **0** for other options

Voicemail feature codes

- *** Backs you up 1 menu
- #** Enter your extension and password from most menus
Also prompts you to leave a **quick memo when set is idle**
- .**
- 1** Listen to new message
- 2** Record and send a message
- 3** Listen to saved message
- #71** Change your password
- #72** Record name
(for Directory and Call Transfer)
- #73** Enter your name using the dial pad
(for Directory)
- 51+ 3** Selects up to 9 separate greetings
(advanced users only)
- 57** Change Basic Busy/No answer Greeting
- 66** Auto play of message information
- 65** Auto play new message
- #74** Extended prompting
(See system user guide)
- 46** Find Me
(Calls you at a series of numbers)
- 61** Message alert on off
- 62** Pager notification
- #2** Stored telephone number
- 63** Undelete messages

Feature Codes

Telephone feature codes (xxx can be a local, extension or group)

Call Forwarding

600 Cancel **601 All** **602 Busy** **603 No Answer**
604 Busy/No Answer **605 From another station** **606 To external number.**

Set a Message on your phone

48 + xx

00 Cancel
01 In a Meeting
02 Out on a call
03 Out to lunch
04 Leave a message
05 Page me
06 Out of town
07 In Tomorrow
08 Return Afternoon
09 On Vacation
10 Gone home
11-30 Customized(See Admin Guide)

Turning on the message light at another phone

41 Send message
42 Cancel message sent
43 Return message

Holding a call

Flash + 11 or *Hold*

12 + XXX pick up Held call

16 Enter speed dial #
00-49 station speed dials
500-699 for System speed dial

17 Save and redial
18 New call (Recall)
19 Last number redial
400 Cancel DND
401 Set DND
44 Call Back
45 Busy station camp on
46 Conference
47 Account code
49 CO Flash (Call waiting)

56 Meet me answer
65+XXX Pick up ringing
extension

55 +1-9 (Page Group) or * Page All

0+XXX pick up parked call

9 or 800-899 Trunk groups

701-749 Outside lines

201-399 Station numbers

500-509 Station groups (DS16)

500-519 Station Groups
(iDCS100 or 500)

0 Operator